MINWAX®
SINCE 1904

Steps to success using Minwax® Wood Finish Penetrating Stain

STEP 1
PRE-STAIN
(optional)

MINWAX
PRE-STAIN
Wood Conditioner

Condition first for most uniform color.

STEP 2
APPLY

BRUSH OR RAG

Apply stain in direction of the grain.

STEP 3
PENETRATE



Wait 5-15 minutes and wipe away excess stain. The longer you wait, the darker/richer the color.

STEP 4
DISPOSE PROPERLY

SPONTANEOUS COMBUSTION

Soak, air-dry flat outdoors & toss rags.

STEP 5
PROTECT

MINWAX
FAST-DRYING
POLYURETHANE

Wait 4-6 hours before applying topcoat.

Clean up with mineral spirits or paint thinner. *Follow manufacturer's safety instructions.*
Total Coverage: Approximately 150 sq. ft. per quart.
Please reference label for full instructions.