ASSEMBLY INSTRUCTION

Remove all items from the carton . Verify all pieces before assembly.

KEY	QTY	DESCRIPTION	KE)	(QTY	DESCRIPTION	KEY	QTY	DESCRIPTION
1	5	Caster	7	1	Backrest	- 12	1	Backrest / Mechanism
2	1	Base	8	1	Backrest Post	12	1	Bolt (10*25mm)+Washers
3	1	Seat Post	0	1	Backrest / Ratchet	13	2	Armrest
4	1	Seat Post Cover	9	1	Screw (8*10mm)	14	2	Arm Width Adjustment
5	1	Mechanism	10	1	M5 Size Allen Wrench	14	2	Knob + Washers
6	1	Seat	11	1	M6 Size Allen Wrench			



eu (f) o t e c h

PARTLIST









Ratchet Back Height Adjustment To raise the back, slowly lift the back up until you hear a series of 4 to 5 clicks. Each click represents a position where the back will lock into place. To lower the back, raise the back all the way up until tension is released - the back will then return to the lowest position without stopping. Raise back up to desired position.

D C B (A) Back angle adjustment lever. (B) Combination seat / back angle adjustment lever with infinite lock. (C) Seat height adjustment lever. (D) Forward tilt lever *While seated, lift lever B and then lean back to activate locking mechanism; *Pull lever D backward to allow seat to tilt forward- or -push lever D forward to straighten seat; *To lock in desired position, push lever B downward. (E) Tension control knob-Turn colockwise to increase tension and counterclockwise to decrease tension. (F) Sliding seat:

Seat depth adjusts for different user leg lengths.

PREVENTIVE MAINTENANCE AND WARNING!

- USE THIS PRODUCT ONLY FOR SEATING ONE PERSON AT A TIME.
 DO NOT USE THIS CHAIR AS A STEP STOOL / LADDER.
 DO NOT SIT ON ANY PART OF THE CHAIR EXCEPT THE SEAT.
 DO NOT USE CHAIR ON UNEVEN FLOOR SURFACES.
 DO NOT USE CHAIR UNLESS ALL BOLTS, SCREWS AND KNOBS

- ARE TIGHTENED
- EVERY SIX MONTHS, PLEASE MAKE SURE ALL BOLTS, SCREWS AND KNOBS ARE FULLY TIGHTENED TO ENSURE STABILITY.
- IF ANY PARTS ARE MISSING, BROKEN, DAMAGED OR WORN, STOP USE OF THE PRODUCT UNTIL REPAIRS ARE MADE USING FACTORY AUTHORIZED PARTS. DISPOSE OF PACKAGING PROPERLY. PLASTIC BAG IS NOT A TOY. DO NOT USE PLASTIC BAG AS HEAD COVERING - IT MAY CAUSE SUFFOCATION. FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY.
- NOTE:SOME SCREWS MAY BE PREASSEMBLED. IF PREASSEMBLED, IGNORE ASSEMBLY INSTRUCTIONS.

