
e u **(f**) o t e c h


ASSEMBLY INSTRUCTION


Remove all items from the carton . Verify all pieces before assembly.


PART LIST

KEY	QTY	DESCRIPTION	KEY	QTY	DESCRIPTION	KEY	QTY	DESCRIPTION
1	5	Caster	7	1	Backrest	12	1	M6 Size Allen Wrench
2	1	Base	8	1	Backrest Post	13	1	Backrest Post Bellow
3	1	Seat Post	9	1	Backrest Screw (8*10mm)	14	2	Arm Bracket
4	1	Seat Post Cover	10	1	M5 Size Allen Wrench	15	2	Armrest
5	1	Mechanism	11	1	Backrest Bolt + Washers	16	2	Arm Width Adjustment
6	1	Seat	' '	'	(10*25mm)	10		Knob + Washers












Ratchet Back Height Adjustment
To raise the back, slowly lift the back up until you hear a series of 4 to 5 clicks. Each click represents a position where the back will lock into place. To lower the back, raise the back all the way up until tension is released - the back will then return to the lowest position without stopping. Raise back up to desired position.



- (A) Back angle adjustment lever.
- (B) Combination seat / back angle adjustment lever with infinite lock.
- (C) Seat height adjustment lever.
- (D) Forward tilt lever
 - *While seated, lift lever B and then lean back to activate locking mechanism;
 - *Pull lever D backward to allow seat to tilt forward- or - push lever D forward to straighten seat;
 - *To lock in desired position, push lever B downward.
- (E) Tension control knob-Turn colockwise to increase tension and counterclockwise to decrease tension.

PREVENTIVE MAINTENANCE AND WARNING!

- USE THIS PRODUCT ONLY FOR SEATING ONE PERSON AT A TIME.
 DO NOT USE THIS CHAIR AS A STEP STOOL / LADDER.
 DO NOT SIT ON ANY PART OF THE CHAIR EXCEPT THE SEAT.
 DO NOT USE CHAIR ON UNEVEN FLOOR SURFACES.
 DO NOT USE CHAIR UNLESS ALL BOLTS, SCREWS AND KNOBS ARE TIGHTENED.
- EVERY SIX MONTHS, PLEASE MAKE SURE ALL BOLTS, SCREWS AND KNOBS ARE FULLY TIGHTENED TO ENSURE STABILITY.

- IF ANY PARTS ARE MISSING, BROKEN, DAMAGED OR WORN, STOP USE OF THE PRODUCT UNTIL REPAIRS ARE MADE USING FACTORY AUTHORIZED PARTS.
 DISPOSE OF PACKAGING PROPERLY, PLASTIC BAG IS NOT A TOY, DO NOT USE PLASTIC BAG AS HEAD COVERING IT MAY CAUSE SUFFOCATION.
 FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY.
 NOTE:SOME SCREWS MAY BE PREASSEMBLED. IF PREASSEMBLED, IGNORE ASSEMBLY INSTRUCTIONS